

# ***ECLIPSE CROSS***



**MITSUBISHI  
MOTORS**

Drive your Ambition







## READY FOR ACTION


Bold lines. Flared fenders. A deeply sculpted wedge like an athlete perched to explode from the starting block. The ECLIPSE CROSS leaves onlookers behind to ponder its steeply raked rear window.



## RESPONSIVE ACCELERATION. MORE POWER FROM EVERY DROP OF FUEL.

### 1.5L direct-injection turbocharged petrol engine

Downsized for efficiency and turbocharged for powerful torque at low-to-mid rpm, the newly developed engine puts instant acceleration at your command. This highly responsive performance was made possible by direct fuel injection, an exhaust manifold-integrated cylinder head, sodium-filled exhaust valves, MIVEC (Mitsubishi Innovative Valve timing Electronic Control system) and more.



### INVECS-III CVT

The advanced CVT supports smooth, powerful acceleration and outstanding fuel efficiency with new step shift control that creates the satisfying sensation of shifting gears.




### Auto Stop & Go [AS&G] **AS&G**

Auto Stop & Go (AS&G) reduces fuel consumption and CO<sub>2</sub> emissions by automatically shutting off the engine when the vehicle is stationary, such as when waiting at traffic lights. The engine restarts immediately when you remove your foot from the brake pedal.

Note: If Brake Auto Hold is active, the engine remains off until the accelerator pedal is pressed.

## Make all the right moves in relaxed comfort.

Handling is stable, intuitive and predictable. Where you point, the ECLIPSE CROSS goes with unerring precision and poise thanks to a fine-tuned suspension, responsive steering and supreme body rigidity — reinforced by spot welding, structural adhesives and a standard strut tower bar over the engine. At the same time, all passengers enjoy an extremely comfortable ride on every road wherever you travel.



Structural adhesive bonding on doors and tailgate openings increases coupling rigidity between body parts. (Images are provided for illustrative purposes only.)

# REASSURING ALL AROUND SAFETY

Advanced safety technology supports safer, more confident driving on the road and in parking lots, day and night. From intelligent sensors that track your surroundings and warn you of danger to active driving assistance and solid passive protection, the ECLIPSE CROSS delivers all around high levels of safety.



## Forward Collision Mitigation System [FCM]

Helps prevent a frontal collision or reduce damage if the collision becomes unavoidable. Responds to vehicles and pedestrians via camera and laser radar.



### Danger of collision



Warning + braking assistance

### High danger of collision



Warning + auto braking


### Extremely high danger of collision



Warning + strong auto braking


## Lane Departure Warning [LDW]

This feature beeps and displays a warning if the vehicle drifts from its lane while the turn signals are not operating.



## Automatic High Beam [AHB]

To increase safety, comfort and driving ease at night, the high beams automatically switch to low beams when vehicles are detected ahead and automatically switch back to high beams so you don't have to remove your hand from the steering wheel to switch the beams manually.



Note:

FCM: The detection and control capabilities of Forward Collision Mitigation [FCM] are supplemental only and do not prevent collisions in every situation. Please drive safely and do not rely solely on this system while driving. FCM operates when a vehicle is in front of your vehicle. FCM is also designed to detect pedestrians, but may not detect them or be activated in some situations. Auto braking is activated for a car ahead when your vehicle is travelling at a speed of approx. 5km/h to 80km/h (approx. 5km/h to 180km/h if your vehicle is equipped with ACC) and for a pedestrian ahead at approx. 5km/h to 65km/h. Since FCM has no function to maintain braking, the brake is released approximately 2 seconds after stopping. To prevent the vehicle from rolling thereafter, the driver may have to hold the brake pedal down. In some cases, FCM may not function if the driver takes actions for accident avoidance through steering or acceleration operation. If you have any questions, please consult your local Mitsubishi Motors dealer/distributor for details.


LDW: Lane Departure Warning is not designed to lessen risks associated with not looking ahead carefully (attention drawn to something on the side, absentmindedness, etc.) or poor visibility caused by bad weather, etc. It is designed to detect the lane at a speed of approx. 65km/h or more. Keep steering your vehicle correctly and drive safely. The system may not be able to detect the lane correctly in some conditions. Please see the owner's manual for additional information.

AHB: This system activates at a speed of approx. 40km/h or more and deactivates at lower speeds. Please see the owner's manual for additional information.

Note: Equipment may vary by market. Please consult your local Mitsubishi Motors dealer/distributor for details.

## Multi Around Monitor


The views from cameras mounted on the front, rear and sides of the vehicle (including a bird's-eye view) can be displayed in various combinations to reveal what is in blind spots and help you park more safely. The vehicle on the screen can be displayed in your choice of 7 provided colours.



Rear view + Bird's-eye view


## Active Stability Control [ASC]

If wheels lose their grip on slippery surfaces or while turning, ASC automatically adjusts engine output and applies braking force at the appropriate wheels to help maintain control and prevent skidding.



## Hill Start Assist [HSA]

When starting on a steep slope, HSA helps prevent you from rolling backwards while you release the brake by maintaining the braking force for up to two seconds until the accelerator is applied.



## RISE body

Collision safety performance is significantly enhanced by Mitsubishi Motors' RISE (Reinforced Impact Safety Evolution) body, which efficiently absorbs energy and maintains high cabin integrity in the event of a collision.



## 7 SRS Airbags

Front airbags, side airbags, curtain airbags and a driver's knee airbag help protect you and your passengers in the event of a collision.



Note:

ASC: The control capabilities of ASC are supplemental only. Please drive safely and never rely solely on these functions while driving. Be sure to use the same specified type and size of tyres on all 4 wheels. Do not install any aftermarket limited slip differential on your vehicle. Please see the owner's manual for additional information.

HSA: Hill Start Assist [HSA] is not a substitute for safe driving. Never rely solely on this function while driving on steep roads. Your vehicle may move backwards if the brake pedal is heavily loaded, or if the road is very steep or slippery. This function is not designed to keep the vehicle stopped in place on uphill slopes for more than 2 seconds. Do not rely on this function to maintain a stopped position as an alternative to depressing the brake pedal. Please see the owner's manual for additional information.

7 SRS Airbags: Airbags are part of a Supplemental Restraint System (SRS). To decrease the risk of injury from a deploying airbag, always fasten your seat belt, sit upright in the middle of the seat and do not lean against the door. Always place children 12 and under in the rear seat if possible and use appropriate child restraints. If using a belt-fixed rear-facing infant restraint in the front seat, activate the SRS airbag cut-off switch. Please see the owner's manual and the instructions provided with your child restraint for additional information.



## FEATURE HIGHLIGHTS



### Power panoramic sunroof

The stylish twin sunroofs with outer sliding glass open up the atmosphere for the driver and all passengers. Each shade can be separately operated to let in refreshing sunlight.

### Rear seat adjustment

The comfortable rear seats with 9-step reclining and 200mm sliding adjustment can be slid all the way back for class-leading legroom. Even then, there is plenty of storage space in back and the 60:40 split seatbacks can be individually lowered for more.




### Electric Parking Brake with Brake Auto Hold

Simply pull the switch up to apply the parking brake or push the switch down to release it. If Brake Auto Hold is active, the vehicle will remain stationary even if you release the brake pedal. Pressing the accelerator releases the brakes.



### Keyless Operation System [KOS]

When carrying the key, you can press a button on the outside of the front doors or tailgate to lock or unlock all the doors and tailgate, and press the engine switch in the cockpit to start or stop the engine.



### Rain sensor

The rain sensor activates the windshield wipers automatically when moisture is detected on the windshield.



### Cruise control

Vehicle speed is automatically maintained without keeping your foot on the accelerator pedal, allowing more relaxed driving on extended journeys. Pressing the brake pedal disengages the system.



### Speed limiter

The speed limiter prevents the vehicle from exceeding the speed you select in most situations. You may need to apply the brakes to prevent the speed from being exceeded when driving downhill. A warning displays and an alarm sounds to alert you if the set speed is exceeded.




### Heated seat

The driver's seat, front passenger's seat provide heaters in the cushions and seatbacks that can be activated or deactivated from easy-to-access switches.




### Auto headlights

When your surroundings become dark, such as at night or when passing through a tunnel, the headlights automatically activate for your safety and convenience.




### Tyre Pressure Monitoring System [TPMS]

TPMS employs sensor-transmitters in the wheels to monitor tyre pressure and illuminates a warning lamp on the combination meter cluster if one or more tyres becomes significantly underinflated.



### Colour LCD Multi-information display

The large, 4.2-inch liquid crystal Multi-information display in the centre of the meter panel is extremely easy to read. It keeps you clearly informed of various useful information on vehicle status, your trip, external temperatures, the ECO drive assist system and more.



EXTERIOR COLOURS

NEW COLOUR



Red Diamond (P62)



Sterling Silver Metallic (U25)

NEW COLOUR



Bronze Metallic (C21)



Silky White Pearl (W13)



Orient Red Metallic (P26)



Titanium Grey Metallic (U17)



Amethyst Black Pearl (X42)



Polar White Solid (W37)

## TECHNICAL SPECIFICATIONS


Model	ECLIPSE CROSS	
Engine	1.5L	
Wheel drive	2WD	
Transmission	CVT	
Seating capacity	5	
<b>Engine</b>		
Code	4B40 MIVEC	
Type	1.5-litre 16-valve DOHC Turbocharged	
Total displacement	(cc)	1,499
Injection system	ECI-MULTI	
Bore x stroke	(mm)	75.0 x 84.8
Compression ratio	10.0	
Maximum output	(kw <PS> /rpm)	120<163> /5,500
Maximum torque	(N-m <kg-m> /rpm)	250<25.5> / 1,800-4,500
<b>Fuel System</b>		
Fuel tank capacity	(L)	63
<b>Performance</b>		
Acceleration* (0-100 km/h)	(sec.)	9.3
Max. Speed**	(km/h)	200
<b>Transmission</b>		
Type	INVECS-III 8-speed Sports Mode CVT	
<b>Suspension</b>		
Front	MacPherson strut, coil springs with stabilizer bar	
Rear	Multi-link trailing arm with stabilizer bar	
<b>Brakes</b>		
Front	Ventilated disc brakes	
Rear	Solid disc brakes	
<b>Steering</b>		
Type	Rack & pinion with electrical power assist	
<b>Dimensions / Weight</b>		
Overall length	(mm)	4405
Overall width	(mm)	1805
Overall height	(mm)	1685
Wheelbase	(mm)	2670
Track	(mm)	Front 1545 / Rear 1545
Curb weight	(kg)	1490
Ground clearance	(mm)	183
<b>Tyre</b>		
Size	225/55R18	

\*Acceleration values vary depending on equipment level.

\*\*Measured by MITSUBISHI MOTORS CORPORATION. Your actual mileage will vary depending on how you drive and maintain your vehicle.

Note: Photo and equipment may vary by market, specifications are subject to change without notice. Please consult your local Mitsubishi Motors dealer/distributor for details.

## DIMENSIONAL VIEWS





Note: Photo and equipment may vary by market, specifications are subject to change without notice. Please consult your local Mitsubishi Motors dealer/distributor for details.



**Hong Kong**

Sole Agent Universal Cars Limited. Tel: (852) 2721-1111  
Unit G5, G/F., Nan Fung Commercial Centre, No. 19 Lam Lok Street,  
Kowloon Bay, Kowloon.  
(Opposite to KMB Depot, Lam Wah Street)



**Macau**

Sub-dealer Harper Engineering (Macau) Limited. Tel: (853) 2871-7585  
Avenida de Venceslau de Morais No. 227-235  
Edif. Industrial Nam Fong Bloco-I, R/C-B1, Macau



[www.30.com.hk](http://www.30.com.hk)

A Sime Darby Motors Company